

SECTION 501-10: Seating
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Memory Set Switch

Removal and Installation

NOTE: For parts identification and location, refer to [Seat — Exploded View, Front](#) in this section.

1. Remove the side shield insert.
 - Release the lower retainers and lift to release the upper retainers.
 - Disconnect the seat control switch electrical connector.
 - Disconnect the memory SET switch electrical connector.
 2. Release the retaining tabs and remove the switch.
 3. To install, reverse the removal procedure.
-