


SECTION 501-14: Handles, Locks, Latches and Entry Systems
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Keyless Entry Keypad



N0001896

Item	Part Number	Description
1	14A626	Keyless entry keypad

Removal and Installation

1. Remove the exterior front door handle. For additional information, refer to [Exterior Front Door Handle](#) in this section.
2. Release the locking tabs and remove the keyless entry keypad.
3. To install, reverse the removal procedure.

mcx30.com