


SECTION 206-03: Front Disc Brake
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Brake Disc Shield

Removal

1. Remove the brake disc. For additional information, refer to [Brake Disc](#) in this section.
2.
 - To install, tighten to 18 Nm (159 lb-in).



Installation

1. To install, reverse the removal procedure.
-