

SECTION 206-09: Anti-Lock Brake System (ABS) and Stability Control
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Stability/Traction Control Switch

Removal and Installation

1. Refer to Passenger Air Bag Deactivation (PAD) Indicator in [Section 501-20B](#).
-

mcx30.com