


Crankshaft Main Bearing Journal-to-Bearing Clearance

NOTE: Refer to the appropriate Section 303-01 for the specification.

NOTE: Crankshaft main bearing journals must be within specifications before checking journal clearance.


1. Remove the crankshaft main bearing caps and crankshaft main bearing.
2. Lay a piece of Plastigage across the face of each crankshaft main bearing surface.



3. **NOTE:** Do not turn the crankshaft while carrying out this procedure.

Install and remove the crankshaft main bearing cap.

4. Verify the crankshaft journal clearance.



mcx30.com