


SECTION 303-07D: Engine Ignition — 6.2L (2V)
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Engine Ignition Components — Exploded View

NOTE: LH side shown, RH side similar



Item	Part Number	Description
1	12286	LH ignition wire (4 required)
2	—	Ignition coil-on-plug electrical connector (part of 9D930) (4 required)

3	W503282	LH ignition coil-on-plug bolt (4 required)
4	12029	LH ignition coil-on-plug (4 required)
5	12405	LH upper spark plug (4 required)
6	12405	LH lower spark plug (4 required)

1. Refer to the procedures and/or exploded views in this section for any Warnings, Notices, Notes, Materials, Specifications, and Special Tools. Items in the exploded views may not be listed in order of removal.
-

mcx30.com