

OVERVIEW > OVERVIEW

The audio system consists of the following:

Main Components

- 4 speakers (Regular Cab)
- 6 speakers (SuperCab and SuperCrew ®)
- 4.2-inch (107 mm) non-touchscreen FCDIM
- ACM
- Audio input jack
- FCIM

Main Features

- Audio extended play (if equipped)
- Battery load shed
- MyKey ® (fleet only)
- Satellite radio (fleet only)
- Speed compensated volume

DESCRIPTION AND OPERATION > INFORMATION AND ENTERTAINMENT SYSTEM - SYSTEM OPERATION AND COMPONENT DESCRIPTION

System Operation

DESCRIPTION AND OPERATION > INFORMATION AND ENTERTAINMENT SYSTEM - SYSTEM OPERATION AND COMPONENT DESCRIPTION > NETWORK MESSAGE CHART

A missing network message is indicated by a U-code DTC and can be the result of intermittent concerns such as damaged wiring or low battery voltage occurrences. Additionally, vehicle repair procedures such as module reprogramming can set these Diagnostic Trouble Codes (DTCs). When a missing message DTC (U-code) sets, it is important to look for symptoms present in the audio system and throughout the vehicle, and to review the complete message list to determine which other modules rely on the same message. Refer to: Communications Network .

When the other modules have been identified, run the self-test for those modules. If the same message is missing from those modules, the identical, or similar lost communication Diagnostic Trouble Codes (DTCs) may be set in those modules. Confirmation of missing messages common to multiple modules can indicate that the originating module is the source of the concern, or that the communication network may be at fault.