

Service Manual: INTERIOR LIGHTING

DESCRIPTION AND OPERATION > INTERIOR LIGHTING - OVERVIEW > OVERVIEW

The interior lighting system consists of:

- Courtesy lamps
- Demand lamps
- Ambient lighting

The courtesy lamps subsystem consists of:

- Interior lamps
- Puddle lamps
- Door ajar switches (integrated into the door latches)
- Courtesy lamp switch (integrated into the front interior lamp)
- Cargo lamps
- Truck bed lamps
- Trailer assist lamp
- DDM
- PDM
- BCM

The courtesy lamps provide illumination to the vehicle interior and below the exterior mirrors when entering or exiting the vehicle or when requested using the courtesy lamp switch located on the front interior lamp assembly.

The demand lamps subsystem consists of:

- Interior lamps (map lamps)
- Vanity mirror lamps
- Glove box lamp
- Cargo lamps
- Truck bed lamps
- Trailer assist lamp
- Cargo lamp switch (integrated into the headlamp switch)
- Floor console front and rear bins
- BCM