

Service Manual: MODULE COMMUNICATIONS NETWORK

DESCRIPTION AND OPERATION > COMMUNICATIONS NETWORK - OVERVIEW > OVERVIEW

Multiplexing is a method of sending 2 or more signals simultaneously over a single circuit. Multiplexing allows 2 or more electronic modules (nodes) to communicate over a twisted wire pair [data (+) and data (-)] network. The information or messages that can be communicated on these wires consists of commands, status or data. Multiplexing reduces the weight of the vehicle by reducing the number of redundant components and electrical wiring.

The vehicle has 2 module communication networks connected to the DLC, located under the instrument panel. The communication networks are:

- HS-CAN1
- HS-CAN2

The vehicle has 2 module communication networks that communicate on the network, but do not communicate directly with the diagnostic scan tool. The GWM translates the messages on these 2 networks, and transfers the signals to the HS-CAN2 to communicate with the diagnostic scan tool. The communication networks are:

- HS-CAN3
- MS-CAN)

DESCRIPTION AND OPERATION > COMMUNICATIONS NETWORK - SYSTEM OPERATION AND COMPONENT DESCRIPTION

System Operation

DESCRIPTION AND OPERATION > COMMUNICATIONS NETWORK - SYSTEM OPERATION AND COMPONENT DESCRIPTION > SYSTEM DIAGRAM