





REMOVAL AND INSTALLATION > RAIN SENSOR > INSTALLATION

1.

Clean the windshield glass area of foreign materials.




2.



NOTE: If the rain sensor gel pack is damaged, install a new rain sensor.

Inspect the rain sensor gel pack for damage.



3.

Install the rain sensor and connect the electrical connector.