



4.

 **NOTE:** This step requires the aid of another technician.

Remove the door.



REMOVAL AND INSTALLATION > FRONT DOOR - SUPERCAB > INSTALLATION

1.

To install, reverse the removal procedure.

2.

 **NOTE:** This step is only necessary when installing a new component.

Check the door-to-body alignment. Align the door as necessary. Refer to: Front Door Alignment - SuperCab .

REMOVAL AND INSTALLATION > FRONT DOOR CHECK ARM > REMOVAL