

- Check corrosion protection, sound damping matting and rubber seals.
- Check paint for overspray, runs, drips and sags.
- Check the cleanliness of the vehicle.
- Perform functional check of the mechanical and electrical components.
- Road test the vehicle.
- Check for squeaks and rattles.
- Check for wind noises and water leaks.


DESCRIPTION AND OPERATION > PLASTIC REPAIRS > PLASTIC COMPONENTS

The following illustration is not all-inclusive of trim levels available. The actual trim level of the vehicle will determine the viability of carrying out a plastics repair. Typically components with moulded-in color or a textured finish are not considered repairable components.

Exterior Plastic Components



NOTE: Regular cab shown in illustration, SuperCab and SuperCrew cab similar.



E188070

Item	Description	Material
1	Front wheel opening trim	TPO (Thermoplastic Olefin)
2	Door applique	ASA (Acrylic Styrene Acrylonitrile)
3	Door opening panel trim cap	PC (Polycarbonate) + ABS (Acrylonitrile Butadiene Styrene)
4	Door opening trim panel	TPO (Thermoplastic Olefin)
5	Cab corner trim	TPO (Thermoplastic Olefin)
6	Rear wheel opening trim	TPO (Thermoplastic Olefin)
7	Pickup box finisher	TPO (Thermoplastic Olefin)

Repair Considerations

Several considerations will determine viability of plastic repair procedure(s):