

Torque

: 129 lb.ft (175 Nm)



Vehicles with trailer tow package

7.

With the help of an assistant, remove the nuts and the rear bumper assembly.

Torque

: 129 lb.ft (175 Nm)



REMOVAL AND INSTALLATION > REAR BUMPER > INSTALLATION

1.

To install, reverse the removal procedure.

DISASSEMBLY AND ASSEMBLY > FRONT BUMPER > DISASSEMBLY



NOTE: Disassembly steps in this procedure may contain assembly details.

All vehicles

1.