

REMOVAL AND INSTALLATION > A-PILLAR OUTER PANEL

Special Tool(s) / General Equipment

6.5 mm Drill Bit
Spherical Cutter
Polydrive Bit Socket
Self-Piercing Rivet (SPR) Remover/Installer
Belt Sander
Blind Rivet Gun
Hot Air Gun
Air Body Saw
MIG/MAG Welding Equipment
Locking Pliers

Materials

Name	Specification
Metal Bonding Adhesive TA-1, 3M™ 08115, Fusor® 108B	-

REMOVAL AND INSTALLATION > A-PILLAR OUTER PANEL > REMOVAL



NOTE: Body side sectioning is prohibited within 50mm of door hinge, door striker and restraints anchoring points.



NOTE: Regular Cab shown, SuperCab and SuperCrew the same.

1.

Depower the SRS. Refer to: Supplemental Restraint System (SRS) Depowering .

2.

Make sure the vehicle is dimensionally correct. Refer to: Body and Frame .

3.