

Install the fender apron panel. Refer to: Fender Apron Panel Reinforcement .

12.

Install the A-pillar outer panel. Refer to: A-Pillar Outer Panel .

REMOVAL AND INSTALLATION > B-PILLAR OUTER PANEL - SUPERCREW

Special Tool(s) / General Equipment

6.5 mm Drill Bit
Spherical Cutter
Self-Piercing Rivet (SPR) Remover/Installer
Belt Sander
Blind Rivet Gun
Air Body Saw
MIG/MAG Welding Equipment
Locking Pliers

Materials

Name	Specification
Metal Bonding Adhesive TA-1, 3M™ 08115, Fusor® 108B	-

REMOVAL AND INSTALLATION > B-PILLAR OUTER PANEL - SUPERCREW > REMOVAL



NOTE: Body side sectioning is prohibited within 50mm of door hinge, door striker and restraints anchoring points.

1.

Depower the SRS. Refer to: Supplemental Restraint System (SRS) Depowering .

2.

Make sure the vehicle is dimensionally correct. Refer to: Body and Frame .

3.