


5.

Disengage the motor drive shaft from the torque rod and remove the motor and bracket assembly.



REMOVAL AND INSTALLATION > POWER RUNNING BOARD (PRB) MOTOR > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > RADIATOR GRILLE > REMOVAL



NOTE: Removal steps in this procedure may contain installation details.

1.

Remove the push pin retainers and remove the air deflector.