




REMOVAL AND INSTALLATION > A-PILLAR TRIM PANEL > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > B-PILLAR TRIM PANEL - REGULAR CAB > REMOVAL



NOTE: LH side shown in illustration, RH side similar.




NOTE: Removal steps in this procedure may contain installation details.

Upper and Lower B-Pillar Trim Panels

1.

Position the seat and the backrest fully forward.



2.