




REMOVAL AND INSTALLATION > LOADSPACE TRIM PANEL - REGULAR CAB > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > LOADSPACE TRIM PANEL - SUPERCAB/SUPERCREW > REMOVAL



NOTE: SuperCrew shown in illustration.



NOTE: Removal steps in this procedure may contain installation details.

1.

Release the seat latch and fold the RH rear seat backrest down.



2.

Release the vehicle jack hook-and-loop strap.