




6.



NOTE: The sub steps should be performed as a single step.


Remove the roof opening panel shield.

1.

Pull up at the one side of the roof opening panel shield.

2.

Carefully rotate the roof opening panel shield in a counter clockwise manner to disengage the remaining guide feet and remove the roof opening panel shield.



REMOVAL AND INSTALLATION > ROOF OPENING PANEL SHIELD > INSTALLATION

1.

To install, reverse the removal procedure.

2.



NOTE: Use the aid of an assistant to install the roof opening panel shield. Insert

the RH rear guide foot into the guide track first and then rotate the shield clockwise working from side-to-side until all guide feet and tabs are fully inserted into the guide foot tracks. Some flexing of the shield and tabs will be necessary.

Guide foot installation.

