



REMOVAL AND INSTALLATION > KEYLESS ENTRY KEYPAD > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > KEYLESS ENTRY REAR ANTENNA > REMOVAL

1.

Remove the tailgate release handle. Refer to: Tailgate Release Handle .

2.

Remove the screws and the keyless entry rear antenna.



REMOVAL AND INSTALLATION > KEYLESS ENTRY REAR ANTENNA > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > REAR DOOR CABLE - SUPERCAB > REMOVAL