

REMOVAL AND INSTALLATION > REAR DOOR LOWER LATCH - SUPERCAB > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > REAR DOOR UPPER LATCH - SUPERCAB > REMOVAL

 *NOTE: LH side shown, RH side similar.*

 *NOTE: Removal steps in this procedure may contain installation details.*

1.

Remove the rear door trim panel. Refer to: Rear Door Trim Panel - SuperCab .

2.

Remove the rear door upper latch bolts.

Torque

: 106 lb.in (12 Nm)



3.

Remove the rear door upper latch.

1.

Remove the rear door upper latch bolt.

Torque

: 106 lb.in (12 Nm)