




REMOVAL AND INSTALLATION > PARKING BRAKE CABLE LH > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > PARKING BRAKE CABLE RH > REMOVAL



NOTE: Removal steps in this procedure may contain installation details.


All vehicles

1.

Release the parking brake cable tension. Refer to Parking Brake Cable Tension Release .

2.

Disconnect the front parking brake cable from the cable union.



3.

Detach the LH parking brake cable from the equalizer bracket.