

REMOVAL AND INSTALLATION > BRAKE CALIPER ANCHOR PLATE > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > BRAKE DISC

Materials

Name	Specification
Metal Brake Parts Cleaner PM-4-A, PM-4-B	-

REMOVAL AND INSTALLATION > BRAKE DISC > REMOVAL



NOTE: Removal steps in this procedure may contain installation details.



NOTE: Vehicles with mechanical parking brake shown in illustration, vehicles with electronic parking brake EPB similar.

1.



WARNING: Service actions on vehicles equipped with electronic parking brakes may cause unexpected parking brake application, which could result in injury to hands or fingers. Put the electronic parking brake system into service mode prior to servicing or removing rear brake components. Failure to follow this instruction may result in serious personal injury.

If equipped with EPB, activate the EPB service mode. Refer to: Electronic Parking Brake (EPB) Service Mode Activation and Deactivation .

2.

Remove the wheel and tire. Refer to: Wheel and Tire .

3.



NOTE: Do not pry in the caliper sight hole to retract the pistons as this can