



2.

 **NOTE:** Make sure that the brake hose is not twisted when installing the brake caliper or damage to the brake flexible hose may occur.

To install, reverse the removal procedure.

3.

Apply the brake pedal several times to verify correct brake system operation.

REMOVAL AND INSTALLATION > BRAKE DISC SHIELD > REMOVAL

 **NOTE:** Removal steps in this procedure may contain installation details.

All vehicles

1.

Remove the axle shaft. Refer to: Axle Shaft - Vehicles With: Ford 8.8 Inch Ring Gear. Refer to: Axle Shaft - Vehicles With: Ford 9.75 Inch Ring Gear.

Vehicles without electronic parking brake (EPB)

2.

Remove the parking brake shoes. Refer to: Parking Brake Shoes .

3.

Remove the 3 bolts and the brake disc shield.

Torque

: 124 lb.in (14 Nm)