

9.

Install the differential carrier. Refer to: Differential Carrier .

DISASSEMBLY AND ASSEMBLY > DIFFERENTIAL CARRIER - VEHICLES WITH: ELECTRONIC LOCKING DIFFERENTIAL (ELD)

Special Tool(s) / General Equipment

 E188621	205-1016 Installer, Differential Bearing TKIT-2014D-FL_ROW TKIT-2014D-ROW2
 E133913	205-153 (T80T-4000-W) Handle
	205-D061 (D83T-4205-C2) Step Plate
 E155534	205-D072 (D97L-4221-A) 2 Jaw Puller
Punch	
Copper Hammer	

Materials

Name	Specification
Motorcraft ® SAE 75W-85 Premium Synthetic Hypoid Gear Lubricant XY-75W85-QL	WSS-M2C942-A
Maximum Strength Retaining Compound Loctite ® 638™	WSK-M2G349-A8

DISASSEMBLY AND ASSEMBLY > DIFFERENTIAL CARRIER - VEHICLES WITH: