

Service Manual: BATTERY, MOUNTING AND CABLES

SPECIFICATIONS > SPECIFICATIONS > GENERAL SPECIFICATIONS**2.7L EcoBoost without climate controlled seats or Alternating Current (AC) power outlet socket**

Item	Specification
Voltage	12 Volts
Battery amps rating	70 amp/hr
Cold Cranking Amps (CCA) measured at -18 C (-0.4 F)	760 Cold Cranking Amps (CCA)

2.7L EcoBoost with climate controlled seats or Alternating Current (AC) power outlet socket

Item	Specification
Voltage	12 Volts
Battery amps rating	80 amp/hr
Cold Cranking Amps (CCA) measured at -18 C (-0.4 F)	800 Cold Cranking Amps (CCA)

3.5L Duratec, 3.5L EcoBoost and 5.0L Ti-VCT without climate controlled seats or Alternating Current (AC) power outlet socket

Item	Specification
Voltage	12 Volts
Battery amps rating	70 amp/hr
Cold Cranking Amps (CCA) measured at -18 C (-0.4 F)	610 Cold Cranking Amps (CCA)

3.5L Duratec, 3.5L EcoBoost and 5.0L Ti-VCT with climate controlled seats or Alternating Current (AC) power outlet socket

Item	Specification
Voltage	12 Volts
Battery amps rating	80 amp/hr
Cold Cranking Amps (CCA) measured at -18 C (-0.4 F)	730 Cold Cranking Amps (CCA)

DESCRIPTION AND OPERATION > BATTERY AND CABLES - OVERVIEW