

Diagnostics in this article assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: Diagnostic Methods .

DTC	Description	Action
B1048:01	Brake Fluid Level Switch: General Electrical Failure	GO to Pinpoint Test S
B1048:7B	Brake Fluid Level Switch: Low Fluid Level	GO to Pinpoint Test S
B10F1:14	Key In Switch: Circuit Short To Ground or Open	GO to Pinpoint Test BE
C1D00:11	Park Brake Apply Switch: Circuit Short To Ground	GO to Pinpoint Test S
All other DTCs	-	REFER to: Body Control Module (BCM) .

DIAGNOSIS AND TESTING > INSTRUMENTATION, MESSAGE CENTER AND WARNING CHIMES > DTC CHART: AUDIO DSP MODULE

Diagnostics in this article assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: Diagnostic Methods .

DTC	Description	Action
B1045:13	Chime: Circuit Open	GO to Pinpoint Test BA
B13FD:13	Chime Input 2: Circuit Open	GO to Pinpoint Test BA
All other DTCs	-	For 8" touchscreen without Sony audio system, REFER to: Information and Entertainment System . For 8" touchscreen with Sony audio system, REFER to: Information and Entertainment System .

DIAGNOSIS AND TESTING > INSTRUMENTATION, MESSAGE CENTER AND WARNING CHIMES > DTC CHART: POWERTRAIN CONTROL MODULE (PCM)

Diagnostics in this article assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: Diagnostic Methods .

DTC	Description	Action
P0461	Fuel Level Sensor "A" Circuit Range/Performance	Refer to ENGINE CONTROLS - INTRODUCTION (EXCEPT