

B1D07:11	Right Turn Indicator: Circuit Short To Ground	A continuous memory and on-demand DTC that sets when the PDM detects an open or short to voltage from the RH exterior mirror turn lamp voltage supply circuit.
U1000:00	Solid State Driver Protection Active -Driver Disabled: No Sub Type Information	This DTC sets when the BCM has temporarily shut down the output driver. The module has temporarily disabled an output because an excessive current draw exists (such as a short to ground). The BCM cannot enable the output until the cause of the short is corrected, the Diagnostic Trouble Codes (DTCs) have been cleared and a successful self-test is run.
U3000:49	Control Module: Internal Electronic Failure	This DTC sets when the BCM has permanently shut down the output driver. The module has permanently disabled an output because an excessive current draw fault (such as a short to ground) has exceeded the limits that the BCM can withstand. CORRECT the cause of the excessive current draw before installing a new BCM.

Possible Sources

- Bulb (halogen headlamps and rear lamps only)
- Headlamp assembly (LED and High Intensity Discharge (HID) headlamps only)
- Rear lamp assembly (LED rear lamps only)
- Exterior mirror
- Wiring, terminals or connectors
- DDM
- PDM
- BCM

DIAGNOSIS AND TESTING > TURN SIGNAL AND HAZARD LAMPS > PINPOINT TESTS > PINPOINT TEST B : ONE TURN SIGNAL LAMP IS INOPERATIVE OR