

Check



NOTE: Refer to the appropriate Engine article for the specifications.


1.



NOTE: The cylinder bore must be within the specifications for taper and out-of-round before fitting a piston.

Measure the cylinder bore in 2 directions.

Select a piston size based on the cylinder bore.



E148355

2.



NOTE: For precision fit, new pistons are divided into 3 categories within each size range based on their relative position within the range. A paint spot or specific size grade on a new piston indicates the position within the size range.

Choose the piston with the correct paint color or specific size grade.

GENERAL PROCEDURES > POWERTRAIN/DRIVETRAIN MOUNT NEUTRALIZING

Adjustment



NOTE: Refer to the appropriate information and procedure for special instructions on loosening and tightening mount fasteners.

1.

With the vehicle in NEUTRAL, position it on a hoist. REFER to: Jacking and Lifting - Overview .