


Loosen the clamp and remove the CAC intake pipe.

Torque

: 48 lb.in (5.4 Nm)




Charge air cooler (CAC) intake pipe - Right side

5.

Loosen the clamps and remove the CAC intake pipe.

Torque

: 48 lb.in (5.4 Nm)



REMOVAL AND INSTALLATION > CHARGE AIR COOLER (CAC) INTAKE PIPE > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > CHARGE AIR COOLER (CAC) OUTLET PIPE > REMOVAL