

B1380:11	Steering Wheel Right Switch Pack: Circuit Short To Ground	GO to Pinpoint Test Y
B1380:17	Steering Wheel Right Switch Pack: Circuit Voltage Above Threshold	GO to Pinpoint Test Y
All other Diagnostic Trouble Codes (DTCs)	-	REFER to: Steering Wheel and Column Electrical Components . See SCCM DTC Chart.

**DIAGNOSIS AND TESTING > INFORMATION AND ENTERTAINMENT SYSTEM >
SYMPTOM CHARTS > SYMPTOM CHART: GENERAL AUDIO SYSTEM**

Condition	Possible Sources	Actions
A module does not respond to the diagnostic scan tool	Fuse Wiring, terminals, or connectors Module	REFER to: Communications Network . See Symptom Chart.
The RH steering wheel switches are inoperative or do not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test Y
The CD player is inoperative or does not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test AA
The speed compensated volume does not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test E
The compass is inoperative or does not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test AD
The audio system does not operate correctly from the FCIM	Refer to the Pinpoint Test	GO to Pinpoint Test Z
The FCIM illumination is inoperative or does not dim	Illumination system concern FCIM	REFER to: Instrument Panel and Interior Switches Illumination .
The FDIM touchscreen is inoperative or does not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test AB
The SIRIUS data services are not available - if equipped	Refer to the Pinpoint Test	GO to Pinpoint Test C

**DIAGNOSIS AND TESTING > INFORMATION AND ENTERTAINMENT SYSTEM >
SYMPTOM CHARTS > SYMPTOM CHART: HD RADIO® SYSTEM**

Condition	Possible Sources	Actions
-----------	------------------	---------