

4.

Remove the microphone from the headliner.

1.

Carefully break the glue loose holding the microphone harness to the headliner.

2.

Pull the harness out until the microphone connector can be accessed and disconnect the electrical connector.



REMOVAL AND INSTALLATION > MICROPHONE > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > REAR DOOR SPEAKER LH > REMOVAL



NOTE: Removal steps in this procedure may contain installation details.

1.

Remove the rear door trim panel. Refer to: Rear Door Trim Panel - SuperCab . Refer to: Rear Door Trim Panel - SuperCrew .

2.

Remove the bolts and the door speaker.

Disconnect the electrical connector.

Torque

: 22 lb.in (2.5 Nm)