

Tailgate Damper

Removal


1. **NOTE:** Removal steps in this procedure may contain installation details.

Remove the RH rear lamp assembly.

Refer to: Rear Lamp Assembly (417-01 Exterior Lighting) .

2. **NOTE:** Note the position of the component before removal.

Disconnect and remove the tailgate damper.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company

mcx30.com