

Front Fender Moulding - Raptor


Base Part Number: Base Part Number: 16038

Removal

NOTE: Removal steps in this procedure may contain installation details.

NOTE: LH side shown, RH side similar.


1. Remove the screws.
Torque: 22 lb.in (2.5 Nm)



E243938



2. Using a non-marring trim tool, disengage the push pin retainers from the fender and remove the moulding.
 - Disconnect the electrical connector when the moulding is disengaged from the fender.



E243939



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company