

Roof Opening Panel Glass

Base Part Number: Base Part Number: 50054


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Place the roof opening panel shield to the fully OPEN position.




2. Place the roof opening panel glass to the VENT position.




3. **NOTE:** *LH side shown, RH side similar.*

Remove both roof opening panel blinds by pulling inward on the top and bottom of the roof opening panel blind. Discard the blinds.



4. **NOTE:** *LH side shown, RH side similar.*

Remove the bolts and with the aid of an assistant, remove the roof opening panel glass
Torque: 35 lb.in (4 Nm)



Installation

1. To install, reverse the removal procedure.
2. Refer to: [Roof Opening Panel Alignment](#) (501-17A Roof Opening Panel, General Procedures).
3. Refer to: [Power Roof Opening Panel Initialization](#) (501-17A Roof Opening Panel, General Procedures).