


Brake Disc Shield

Removal

1. Remove the brake disc.
Refer to: [Brake Disc](#) (206-03 Front Disc Brake, Removal and Installation).
2. Remove the 3 bolts and the brake disc shield.
Torque: 155 lb.in (17.5 Nm)



Installation

1. To install, reverse the removal procedure.

mcx30.com