


# Parking Brake Warning Indicator Switch


## Removal

**NOTE:** Removal steps in this procedure may contain installation details.


1. Disconnect the parking brake indicator switch electrical connector.



2. Remove the 2 bolts, loosen the remaining bolt 2 full turns and position the parking brake control aside.  
Torque: 177 lb.in (20 Nm)



3. Remove the bolt and the parking brake indicator switch.  
*Torque: 18 lb.in (2 Nm)*



## Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company