


Brake Pedal Control Switch


Removal

NOTE: Removal steps in this procedure may contain installation details.


1. Pull outward on the steering column opening cover detaching the 7 clips and allow the cover to hinge downward.



2. Disconnect the adjustable pedal switch electrical connector.



3. Press inward on the 2 clips and remove the adjustable pedal switch.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company