


Engine

Base Part Number: Base Part Number: 6L084

Special Tool(s) / General Equipment

 E129694	100-001 (T50T-100-A) Slide Hammer
 E234304	205-142 (T80T-4000-J) Installer, Differential Bearing Cone
 E133913	205-153 (T80T-4000-W) Handle
 E175042	303-1247 VCT Spark Plug Tube Seal Remover and Installer TKIT-2006UF-FLM TKIT-2006UF-ROW
 E134603	303-409 (T92C-6700-CH) Remover, Crankshaft Seal TKIT-1992-FH/FMH/FLMH TKIT-1993-LMH/MH