


Engine

Base Part Number: Base Part Number: 6L084

Special Tool(s) / General Equipment

 E234304	205-142 (T80T-4000-J) Installer, Differential Bearing Cone
 E133913	205-153 (T80T-4000-W) Handle
 E175042	303-1247 VCT Spark Plug Tube Seal Remover and Installer TKIT-2006UF-FLM TKIT-2006UF-ROW
 ST2980-A	303-1250 Seal Installer, Rear Main TKIT-2006UFFLM
 E216458	303-1531 Installer, Front Crank Seal and Damper