

High-Pressure Fuel Pump Drive Unit

Removal and Installation

1. The high-pressure fuel pump drive unit is part of the right cylinder head.
Refer to: [Cylinder Head RH](#) (303-01D Engine - 5.0L 32V Ti-VCT, Removal and Installation).

Copyright © 2018 Ford Motor Company

mcx30.com