

Evaporative Emissions

Engine Diagnostic Information

For PCM DTC,
REFER to: [Electronic Engine Controls](#) (303-14D Electronic Engine Controls - 5.0L 32V Ti-VCT, Diagnosis and Testing).

For driveability symptoms without DTC, Refer to Powertrain Control/Emissions Diagnosis (PC/ED) manual. See Section 3, Symptom Charts.

Copyright © 2018 Ford Motor Company
