



Electronic Engine Controls - Component Location

Electronic Engine Controls- Front



Item	Description
1	RH Intake VCT Oil Control Solenoid
2	RH Exhaust VCT Oil Control Solenoid
3	LH Intake VCT Oil Control Solenoid
4	LH Exhaust VCT Oil Control Solenoid
5	Oil Pressure Control Solenoid

Electronic Engine Controls - Rear




E257738

Item	Description
1	FRP and temperature sensor
2	LH CMP sensors
3	LH IMRC Actuator
4	FRP sensor
5	MAPT sensor
6	LH HO2S
7	LH Catalyst Monitor sensor
8	RH Catalyst Monitor sensor


9	RH HO2S
10	CKP sensor
11	CHT sensor
12	RH CMP sensors
13	RH IMRC Actuator
14	IMRC Solenoid

KS



Item	Description
1	KS
2	KS

Powertrain Control Module (PCM)



Item	Description
1	PCM