


Downshift Paddle Switch


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the driver air bag.
Refer to: [Driver Airbag](#) (501-20B Supplemental Restraint System, Removal and Installation).
2. Disconnect the downshift paddle switch electrical connector.



3. Remove the screws and the downshift paddle switch.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company
