

SelectShift Switch - Vehicles With: Column Shift

Removal

1. **NOTE:** *The SelectShift™ switch is not serviced separately. If a new SelectShift™ switch is required, install a new column shift selector lever.*

Install a new column shift selector lever.

Refer to: [Selector Lever Assembly - Vehicles With: Column Shift](#) (307-05 Automatic Transmission External Controls, Removal and Installation).

Installation

1. **NOTE:** *The SelectShift™ switch is not serviced separately. If a new SelectShift™ switch is required, install a new column shift selector lever.*

Install a new column shift selector lever.

Refer to: [Selector Lever Assembly - Vehicles With: Column Shift](#) (307-05 Automatic Transmission External Controls, Removal and Installation).