

Transmission Control Switch (TCS) - Vehicles With: Floor Shift

Removal

1. **NOTE:** *The TCS is not serviced separately. If a new TCS is required, install a new selector lever knob.*

Install a new selector lever knob.

Refer to: [Selector Lever Knob](#) (307-05 Automatic Transmission External Controls, Removal and Installation).

Installation

1. **NOTE:** *The TCS is not serviced separately. If a new TCS is required, install a new selector lever knob.*

Install a new selector lever knob.

Refer to: [Selector Lever Knob](#) (307-05 Automatic Transmission External Controls, Removal and Installation).