



Climate Control System - Raptor, Vehicles With: Electronic Manual Temperature Control (EMTC) - Component Location




Item	Description
1	In-Vehicle Temperature & Humidity Sensor
2	Auto Lamp Sensor
3	FCIM & HVAC Module



Item	Description
1	Air Distribution Door Actuator
2	Driver Side Register Air Discharge Temperature Sensor
3	Air Inlet Door Actuator
4	Cabin Air Filter
5	Blower Motor Control Module
6	Evaporator
7	Evaporator Temperature Sensor
8	Driver Side Temperature Door Actuator
9	Heater Core
10	Driver Side Footwell Air Discharge Temperature Sensor

3.5L EcoBoost



Item	Description
1	A/C Compressor
2	Condenser Outlet Line
3	Evaporator Outlet Line
4	Thermostatic Expansion Valve
5	Climate Control Housing
6	A/C Compressor Outlet Line
7	A/C Compressor Inlet Line
8	Condenser
9	Desiccant Bag
10	Ambient Air Temperature Sensor
11	A/C Pressure Transducer

mcx30.com