


Ambient Air Temperature Sensor - Raptor

Base Part Number: Base Part Number: 12A647

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the upper active grille shutter.
Refer to: Active Grille Shutter (501-02) .
2. Detach and remove the ambient air temperature sensor.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company

mcx30.com