

Evaporator

Base Part Number: Base Part Number: 19850

Removal

NOTE: *The evaporator is available only as part of the climate control housing.*

1. Remove the climate control housing.
Refer to: Climate Control Housing (412-00) .

Installation

1. Transfer the components from the old housing to the new housing as required.
2. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company
