


Sunload Sensor

Special Tool(s) / General Equipment

Interior Trim Remover

Removal

1. Remove the sunload sensor and disconnect the electrical connector.
Use the General Equipment: Interior Trim Remover



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company

mcx30.com